

LIGHT 冷光灯

UP-MENU 上-選單

DOWN 下




START-STOP 开始-停止

BACK 返回

FIRST BOOT

第一次启动



Hold Down
UP-MENU

长按
上-选单





WATCH FACE 表盘

Watch Face 表盘


Apply 应用
Customize 自定义
Delete 删除


Dial 调整
Hands 指针
Data 数据
Accent Color 主题颜色
Bkgd. Color 背景颜色
Done 完成














































Short Press
START-STOP



短压
开始-停止





MARINE FEATURES - BOAT / SAIL RACE 水上功能 - 划船/风帆赛





MARINE FEATURES - FISH / TIDES 水上功能 – 钓鱼/潮汐表




MARINE FEATURES - ANCHOR / AUTOPILOT 水上功能 – 锚/自动驾驶




MARINE FEATURES - BOAT DATA / FUSION-LINK 水上功能 – 船只资料/FUSION-LINK




OUTDOOR FEATURES - SUP / ROW 户外功能 – 桨板冲浪/划船



OUTDOOR FEATURES - OPEN WATER / TRACK ME 户外功能 – 公开水域/追踪活动




OUTDOOR FEATURES - PROJECT WPT. 户外功能 - 投影航点




OUTDOOR FEATURES - NAVIGATE 户外功能 - 导航




OUTDOOR FEATURES - RUN / HIKE 户外功能 - 跑步/徒步



OUTDOOR FEATURES - BIKE / GOLF 户外功能 - 自行车/高尔夫





Add 添加	Short Press 短压 START-STOP 开始-停止			
		MTB 山地骑行	Set as favorite? 设置为最爱?	Yes / No 是 / 否
		Pool Swim 泳池游泳	Set as favorite? 设置为最爱?	Yes / No 是 / 否
		Triathlon 铁人三项	Set as favorite? 设置为最爱?	Yes / No 是 / 否
		Ski 滑雪	Set as favorite? 设置为最爱?	Yes / No 是 / 否
		Snowboard 滑雪板	Set as favorite? 设置为最爱?	Yes / No 是 / 否
		XC Ski 越野滑雪	Set as favorite? 设置为最爱?	Yes / No 是 / 否
		Row Indoor 室内划船	Set as favorite? 设置为最爱?	Yes / No 是 / 否
		TruSwing	Set as favorite? 设置为最爱?	Yes / No 是 / 否
		Walk 走路	Set as favorite? 设置为最爱?	Yes / No 是 / 否
		HRV Stress HRV压力分数	Set as favorite? 设置为最爱?	Yes / No 是 / 否
		Swimrun 游泳/跑步	Set as favorite? 设置为最爱?	Yes / No 是 / 否
		Strength 力量训练	Set as favorite? 设置为最爱?	Yes / No 是 / 否
		Cardio 有氧运动	Set as favorite? 设置为最爱?	Yes / No 是 / 否
		Jumpmaster 跳伞大师	Set as favorite? 设置为最爱?	Yes / No 是 / 否
		Tactical 战术	Set as favorite? 设置为最爱?	Yes / No 是 / 否
		Other 其他		